Multifunction Power Bank DVR
User Manual

Profile

This manual introduces how to operate this product and the detailed information about this product. Before starting to operate it, please be sure that you have read this manual and understood it completely and correctly. Hope this product to meet your needs and long-term service to you!

DV Function Introduction

This product is a multifunction Power Bank DVR provides the DV functions including video, audio, and motion detection recording but without power bank function, which cannot charge other electrical products. It supports TF Card and the max memory can be up to 32GB, the high capacity batteries provide the enough power for long time recording. Just because of its special design and big batteries features, it can be used as home security monitor and

portable DVR.

Feature:

- Covert video camera recorder
- High storage li-battery to support long time recording
- One button operation—easy to use
- HD 720p and H.264 format
- Support motion detection Recording
- Portable & Home Security Monitor

Operation:

（1） Install memory card

Check the back side of the product, and insert the micro sd card carefully, because this camera is with HD resolution, please insert a big enough memory card (video file consumes 3GB per hour)

（2） Stick the mirror face

Stick the back side mirror face after you insert the micro sd card well
(Please test the camera and make sure it works before you stick the mirror face back)

（3） Replace new memory card if necessary

Please find a knife or something else to open the mirror face of the power bank, and you will find the memory card,
Pls take off the memory card carefully, if necessary please using a tool to do help

After you replace the new memory card, pls make sure it works, and then stick the mirror face back to the power bank carefully

（4） Reset Time stamp

- Turn Off the camera
- Connect the camera and PC with USB Cable
- Open the Removable hard disk (micro sd card)
- Create a txt file and named as time.txt
- Input and edit the time as this form:2012.11.08 01:01:01
- Save and get exit

- Disconnect PC and turn On the camera

（5） Power on

Keep pressing the power button for around 3seconds till the red light is on.

（6） Recoding

While the red light on (standby mode), please press the button one time shortly, the red light will flash twice and be off.

（7） Save video

Press the button one time shortly while recording, the red light on again, it becomes to standby mode and video was saved

（8） Motion detection mode

Under standby mode please keep pressing the power button for around 3 seconds and release, the blue light will flash twice and die, at the same time red light will die, too.

When it detects any movement, the blue light will flash one time shortly and start recording. It will not record without detecting movement.

（9） Save Video

Press the button one time shortly, video file will be saved and red light on, becomes to standby mode

（10） Power off

Under the standby mode, please keep pressing the power button for 6 seconds till the red and blue lights flash twice and off at the same time.

（11） Reset

Because of the wrong operation or any other unknown reasons, there is no any feedback from the camera, please find one toothpick to press the reset pinhole beside the camera hole

（12） Low power or Full memory

When it is low power or full memory, the red and blue indicator will flash quickly and off

（13） Charge

Use the usb cable to connect product to PC to charge (about 4hours) or use AC adapter to charge. When charging, the red and blue light will continue flash, if the battery was full; the red light will be off and blue light on. (100% indicator)

（14） File Storage and replay

Please connect the power bank to your PC and read the video file to replay.

You can copy the video file and save it to your PC

Using media player which can support AVI format

2、Specifications

Pixels	5.0 Mega CMOS
Video Resolution	1280*720
Video Form	AVI
FPS	30fps
View Angle	90°
Motion Detection Distance	Direct 6 meters

Low Illumination	1LUX
Battery Capacity	3000MAH
Recording Time	More than 8 hours
Motion Detection Recording Time	More than 48hours
Recording Audio Area	40 ㎡
Power Consumption	150MA/3.7V
Store Temperature	-20-80℃
Operation Temperature	-10-60℃
Operation Humidity	15-85%RH
Memory	TF Card
Max.	32GB
Software	Media player/KMplayer
Data Transfer Interface	USB1.1/2.0
Operation System	2000/XP/Visat32/Win7
Memory Consumption	3GB/hour
Charge Time	About 4 hours

Notice:

Function: This product has camera recorder function only

Noise: when the battery is very low, audio recording will have little noise

Place of using: It cannot be used in the illegal place, before using it, please pay attention to the law.

Proposal: The factory will improve the product in order to improve the service and using feels of these products. Please try to contact your seller to if you have any Proposal.

Working Temperature: Please use it in the suitable temperature which the man can bear.

Working Humidity: Please do not use it in humidity place.

LUX: Please use it in the place with enough light; please do not make the lens straight to strong light source.

Clearance: Please do not use it in the dirty place, please clear it with soft cloth and clear it smoothly. Please do not use it in strong magnetic field or strong electrics field.